

MAVERICK TAILGATER ASSEMBLY INSTRUCTIONS

This task is mostly safely accomplished with two people that can lift at least 75 lbs.

What you'll need:

- Pallet bolt: 3/8"
- Caster nut and bolt: 1/4"
- Scissors

- 1 Remove plastic wrap and foam. Be careful not to scratch the paint or stainless underneath!
- 2 Using a ratchet, wrench, or power driver, remove the screws that hold the grill to the pallet. Generally, these are 3/8". The screws can be discarded.
- 3 Your wheels / casters and bolt kit should be in a cardboard box inside the grill. Take that out and open it.
- 4 Open the lid and remove the grates and charcoal pan and set them aside.
- 5 Each person should grab the grill by a handle -- take it off of the pallet and set the feet on the ground.
- 6 Next, tilt the grill up by holding one handle until you have enough room to fit casters underneath it.



MAVERICK TAILGATER ASSEMBLY INSTRUCTIONS

- 7** While the grill is tilted, put the fixed wheels on the two feet in the air. It does not matter which side the fixed wheels go on. Secure with four bolts per wheel. Generally these are 1/4"
- 8** Set the grill back down.
- 9** Next, lift the grill up by the handles and have the other person place a swivel wheel under each foot and loosely fasten with two bolts. You might put a block behind the fixed wheels so they do not roll when the grill is tilted.
- 10** Set the grill back down.
- 11** Finish securing swivel wheels with the remaining bolts. All bolts should be tightened.
- 12** Finally, put the grates back into place, being sure they slide in under their support brackets.
- 13** Done!

