


Install the module on your grill

- First, unplug the pellet grill from A/C power
- The Wi-Fi Module is connected to the grill control with a short telco cable (RJ11 6P/4C)
- Connect one end of the RJ11 cable to the Wi-Fi Module via an RJ11 connector (right side) as shown below
- Connect the other end to an existing RJ11 connector on the grill control.




Mount the module on your grill

- The mounting location of the Wi-Fi module should be on a wall of the hopper below the handle, centered, and 3” from the bottom of the hopper
- Drill the mounting hole with a 3/8” drill bit. Deburr the hole inside and out with a round file or with a larger drill bit




- The hardware to mount the Wi-Fi module consists of a spacer, a shoulder washer, a lock washer and mounting nut
- Place the spacer onto the Wi-Fi antennae mount as shown above
- While holding the module in place, place the shoulder washer onto the antennae mount with the shoulder of the washer fitting inside of the drilled hole
- While still holding the Wi-Fi Module in place, screw the antennae on (hand tight). Connect the Wi-Fi Module to the grill control with the supplied telco connector as shown previously and the installation is complete.


1. Download the Pitts & Spitts app from the app store; select the top of the two apps shown




2. Open the app. Touch the Gear icon in the top right corner




3. Touch the Set Up Grill button




4. Making sure your phone's Bluetooth is on, select the Grill




5. Your grill is thinking...




6. Enter your grill name of choice




7. Select your WiFi network




8. Enter your password – BE SURE IT IS CORRECT!




9. When it appears under the Saved Networks and the signal symbol is green, it is connected



10. Choose the network and click Connect; press the back arrow



11. Select your device under the Grill device selection section; press the back arrow



12. If your grill is on, this is your home screen and you're ready to cook!

