

## ADJUSTABLE CHARCOAL GRILL ASSEMBLY INSTRUCTIONS

This task is mostly safely accomplished with two people that can lift at least 75 lbs.

### What you'll need:

- Pallet bolt: 3/8"
- Caster nut and bolt: 9/16"
- Scissors

- 1 Remove plastic wrap and foam. Be careful not to scratch the paint or stainless underneath!
- 2 Using a ratchet, wrench, or power driver, remove the screws that hold the grill to the pallet. Generally, these are 3/8". The screws can be discarded.
- 3 Your wheels / casters and bolt kit should be in a cardboard box inside the grill. Take that out and open it.
- 4 Open the lid and remove the grates and set them aside.
- 5 While one person grabs the grill by the handles, the other should grab it by the handle on the hopper -- take it off of the pallet and set the feet on the ground.



## ADJUSTABLE CHARCOAL GRILL ASSEMBLY INSTRUCTIONS

- 6** Next, lift the grill up until it is leaning on the handles – the charcoal grate handle will be “up in the air”. When doing so, put some of the foam under the handles to avoid them scratching on the ground. Also, move the pallet out from under it.
- 7** While the grill is leaning on the handles, put the fixed wheels on the two feet nearest the grate handle. Secure with four bolts per wheel. Generally these are 9/16”
- 8** Set the grill back down.
- 9** Next, lift the grill up by the handles and have the other person place a swivel wheel under each foot and loosely fasten with two bolts.
- 10** Set the grill back down.
- 11** Finish securing swivel wheels with the remaining bolts. All bolts should be tightened.
- 12** Finally, put the grates back into place.
- 13** Done!

